

# SPA-QUICK START





# Step 1

Fill Spa using the Carbon Filter that was provided in the "CalSalt" Filtration Kit.

## Step 2

Turn ON Spa and set "CalSalt" Filtration Chlorine time to Zero (0). See manual for Control Panel settings configurations.

#### Step 3

Balance the Spa water levels (Use Test strips and Chemicals provided in Kit).

• Total Alkalinity, pH, Total Hardness, Total Chlorine.

PREFERRED LEVELS	FACTORS			
2000-2500 ppm (3000 ppm for Swim Spa)	Salt			
7.2-7.8	PH			
3.0-5.0	Free Chlorine			
100-120 ppm	Total Alkalinity			
150-200 ppm	Calcium Hardness			

## Step 4

Take a sample of the water with a cup. Check Salt level with Salt Strips provided in Kit. Refer to Salt Table below to know the amount of salt required. The amount of Salt needed to achieve 2000ppm-2500ppm level on the spa is on the table.

Spa Size in	Current Salinity Level (ppm) in Spa							
Gallons	0ppm	500ppm	1000ppm	1500ppm	2000ppm	2500ppm	3000ppm	
400-450 Gallons 7 ft. Spa	Add 8.4 Ibs	Add 6.7 Ibs	Add 5.0 Ibs	Add 3.3 Ibs	Add 1.7 Ibs	0	0	
450-500 Gallons 8 ff. Spa	Add 10.4 lbs	Add 8.4 Ibs	Add 6.3 Ibs	Add 4.2 Ibs	Add 2.1 Ibs	0	0	
750-850 Gallons 11 fl. Spa	Add 14.3 lbs	Add 12.0 lbs	Add 9.7 Ibs	Add 7.4 Ibs	5.1 lbs	0	0	
1550-1650 Gallons 13 ff. Swim Spa	Add 30.0 lbs	Add 27.5 lbs	Add 25.0 Ibs	Add 22.5 Ibs	Add 20.0 Ibs	Add 17.5 Ibs	0	

#### Step 5

After water chemistry is adequately balanced, turn ON Pump to Hi-Speed and add "CalSalt" bags (Reference: Step.4). Wait for the Salt to dissolve. (At least 1 hour)

#### Step 6

Remember to wait at least an hour before adjusting the Chlorine time to the recommended hour setup by Spa size.

#### Step 7

Proceed by adjusting the setting on Chlorine time Control Panel depending on spa size. Ex. (Spa Size / Chlorine Time) Subsequently 7 ft. / 3 Hours; 8 ft. / 4 hours; 13 ft. / 10 hours.

## Step 8

After the 2 Days of supervising the changes of Spa levels use the Test Strips to see if any adjustments are needed.



Monitor every 3 to 4 days with recommended procedures.

# Step 10

Routine check-ups are important to achieve desired water levels.